



# SERVICE WALLS

USED AS SEPARATING WALLS TO ISOLATE AND SECURE  
PLANT ROOMS FROM OTHER AREAS OF THE BUILDING  
HEB 1207




VERTICAL CROSS SECTION DETAIL A-A



## ISOMETRIC VIEW

NTS



DETAIL PLAN VIEW

SERVICE SHAFT WALL - OPTION 1							
CODE	APPLICATION	WALL THICKNESS	WALL HEIGHT 'H'	FRL (A)	R.+C <sub>v</sub> (B)	SYSTEM COMPONENT VARIATIONS	
						LINING	PANEL
HEB1207	BARE SHAFT	75mm	UP TO 4.65m HIGH	-/120/120	33dB	NIL	75mm POWERPANEL SP

REFER TO DESIGN AND INSTALLATION GUIDES FOR HIGH RISE SERVICE SHAFT & SCISSOR STAIR WALLS (HELIT 032 ) FOR MORE DETAILED INFORMATION

<b>CSR BUILDING PRODUCTS LTD</b> Head Office: T1111 3, 39 DELHI RD, NORTH RYDE NSW 2113 LOCKED BAG 1345, NORTH RYDE BC NSW 1670 A.B.N. 55 008 631 356 Ph: 1300 369 448 www.hebelaustralia.com.au	<b>hebel</b> The better way to build CSR Building Products Limited A.B.N. 55 008 631 356	SYSTEM CODE HEB1207	TITLE HEBEL SERVICE WALLS		
		DESIGN GUIDE REFERENCE ---	SCALE 1:5 @ A3	SHEET SIZE A3	DRAWN DG
			SHEET NO. 1 of 1	CHECK CW	REVISION B